













Instructions



Use a pen whose ink has dried out, or a tracer, to trace lines first.



Separate all parts along the lines.



Fold and glue J01according to the assembly instruction.



Letter "J" is now done.