







Instructions



Use a pen whose ink has dried out, or a tracer, to trace lines first.



Fold and glue Z01 and Z02 respectively.



Separate all parts along the lines. Mark their identity on the back to avoid confusion.



Glue Z01 and Z02 according to the assembly instruction, Letter "Z" is now done.